

LET'S MANUFACTURE TOMORROW



**NOVAMID®
ID1030 CF10**

NOVAMID® ID1030 CF10

Novamid® ID1030 CF10 is a new polyamide for 3D printing parts with properties close to what is usually achievable only by injection molding. With a loading of 10% carbon fiber, it produces stronger, tougher and stiffer 3D printed parts while it can be printed at the same speeds as unreinforced plastics.

Novamid® ID1030 CF10 is a new carbon fiber filled PA6/66 copolymer filament for 3D printing durable structural parts with high dimensional stability, warpage free. Filled with only 10% of actual carbon fiber – much lower than most carbon filled materials – Novamid® ID1030 CF10 enables parts that are stronger, stiffer and tougher parts with higher tensile strength and modulus.

Designed especially for 3D printing, its excellent mechanical properties and smooth appearance make it ideal for demanding automotive structural applications that require robust performance at elevated temperatures.

The material can be printed on standard desktop fused filament fabrication (FFF) machines with a hardened nozzle. Tests have shown that users can run their printers at the same speeds as with unreinforced plastics, while achieving considerably better strength and toughness.

Tested on open FFF platforms

Novamid® ID 1030 CF10 has been tested on several open FFF platforms, including on GermanRepRap and the new Ultimaker S5. Its printing profile is available on Ultimaker's Cura platform.

Key Benefits

- 3D printable at same speed as unreinforced plastics thanks to low carbon loading of 10%
- Enables properties close to what is usually achievable only by injection molding
- Durable parts with good mechanical properties due to high inter-layer strength
- Made from DSM Novamid copolyamide PA6/66, which is used in automotive and electronics for many years
- HDT of 184°C at 1.8MPa
- Very low warpage compared to unfilled PA
- Characteristic matte black surface-finish with less roughness

Applications

- Automotive under-the-hood applications
- Protective and supporting sports gear
- High performance functional parts
- Manufacturing jigs and fixtures
- Medical braces and prosthetics
- Light weight applications
- Applications requiring durable and stiff parts with good mechanical properties

NOVAMID® ID1030 CF10

Material property	Value	Unit	Test method
Maximum tensile stress (3D printed tensile bars)	0°-90°	Mpa	ISO 527-1/-2
Maximum tensile stress (3D printed tensile bars)	45°-45°	MPa	ISO 527-1/-2
Tensile modulus (3D printed tensile bars)	0°-90°	MPa	ISO 527-1/-2
Tensile modulus (3D printed tensile bars)	45°-45°	MPa	ISO 527-1/-2
Elongation at break (3D printed tensile bars)	0°-90°	%	ISO 527-1/-2
Elongation at break (3D printed tensile bars)	45°-45°	%	ISO 527-1/-2
Tensile modulus (3D printed: upright Z direction)	220	MPa	ISO 527-1/-2
Stress at break (3D printed: upright Z direction)	20	MPa	ISO 527-1/-2
Strain at break (3D printed: upright Z direction)	55	%	ISO 527-1/-2

**For more information and buying options, please visit
www.dsm.com/additive-manufacturing/**

DSM – Bright Science. Brighter Living.™

All information supplied by or on behalf of DSM in relation to its products, whether in the nature of data, recommendations or otherwise, is supported by research and, in good faith, believed reliable, but DSM assumes no liability and makes no warranties of any kind, express or implied, including, but not limited to, those of title, merchantability, fitness for a particular purpose or non-infringement or any warranty arising from a course of dealing, usage, or trade practice whatsoever in respect of application, processing or use made of aforementioned information, or product. The user assumes all responsibility for the use of all information provided and shall verify quality and other properties or any consequences from the use of all such information. Novamid is a trademark of DSM.

Copyright © DSM 2018. All rights reserved. No part of the information may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of DSM. Doc 0003-01

